

Beginning with the version 2.20 the program can generate a pdf document showing the iMCU parameter.

Customizing the header text

The default header text is:

Vossloh-Schwabe Deutschland GmbH
Wasenstraße 25, 73660 Urbach

If you create a text file *pdf.ini* (using a text editor like notepad or similar), and you copy this file to the folder where the program exe is, it is possible to change the header text.

The content of the pdf.ini is:

[Header]

Line1= this is the 1st line (bold)

Line2= this is the 2nd line

Using the PDF Function

After pushing the **PDF** button, you can enter:

- Project name (the actual date will be added automatically)
- Luminaire brand
- Driver brand

All these input fields are length limited. Because the font-character-width is different for each character, (for example "W" and "i"), the maximal allowed text length depends on the text content. Please check the pdf output and shorten/modify the text if the end is cut.

If you leave the project name field empty, the project section will not be displayed.